

# YAMAHA TY175 BOLT ON FOOTRESTS FITTING INSTRUCTIONS AND MODIFICATIONS



Complete kit including optional footrests



1. LH side - Remove standard footrest and bracket



2. LH side - Re-fit spindle using the supplied spacers



3. LH side - Bolt on new bracket and fit footrest



4. RH side - Remove standard footrest and bracket



5. RH side - Remove lug back to the point indicated



6. RH side - Photo shows the lug has been removed



7. RH side - Drill an 8mm hole and insert the supplied bolt from the rear of the hole to secure footrest bracket



8. RH side - Using footrest bracket as a template drill a second 8mm hole as shown



9. RH side - Fit the supplied countersunk bolt as shown



10. Photo shows the bolts from rear of the frame



11. RH side - Fit brake pedal and footrest